


Set-up

step 2

step 1


Installation



Shoulder strap or cockpit installation recommended

ON / OFF

Searching GPS*




ON : 3 sec.
OFF : 3 sec.

Battery level:
3x
2x
1x




Volume




default parameter

Vario settings




default parameter

Weak lift buzzer (during flight)




default parameter

Sink alarm settings




default parameter

Voice: Manual mode



Default announcements are: altitude, speed, climb rate

Voice: Auto mode (during flight)



Default triggers are: altitude 100m, distance 1km

For detailed user manual
with text, check out
Stodeus website :



stodeus.com

UltraBip

user manual




User manual available in
other languages !
Download it on your
smartphone.

Always on top.



Web-app Configurator




Connectivity

Android & iOS




More information on stodeus.com

Bluetooth discovery:
ON → 32 min.



Battery charge

Solar charge:
Instrument ON: 40h
Instrument OFF: 20h




USB charge: 2h
ON / OFF



Do not place the device behind a window or the windshield
of a car as charging temperature must not exceed 60°C.

USB track transfer




KML track file: Google Earth
IGC track file: VisuGPS, XContest, national federation websites, etc

Language selection & Reset

Reset
20 sec.

ON
4 sec.


Default parameters



Download more languages online, miles and knots available

UltraBip

SOLAR · GPS · INSTANT VARIO
VOICE ASSISTANT · BLUETOOTH



QUICK START



STODEUS
SOLAR PARAGLIDING INSTRUMENTS